

How to assemble your Ped-O-Pull

PARTS INCLUDED:

(1) wooden base	Kidney 607-021/Square 607-020
(1) 19" pole	PED0005
(1) 84" pole	PED0006
(2) T-shaped wall supports with hex nuts	PED0004
(2) Handles	101-016
(2) Yellow springs	SPR9002
(4) Flat head wood screws	GEN9271
(4) Lag bolts	PED0003
(1) Large bolt	GEN9083
(1) Large washer	GEN9084
(4) Washer	GEN9204

1. Insert the 84" Pole through the underside of the wooden base (the underside has a recess cut into it with four small screw holes and one large hole for the post).
2. Use 4 flat head wood screws to attach the pole flange to the wooden base.
3. Use large bolt and washer to connect the 19" pole to the 84" pole.
4. Loosely screw T-shaped wall supports into the 84" pole. Position the entire unit upright against the wall where it is going to be attached. Screw T-shaped wall supports in or out so the Ped-o-Pull base is located flat on the floor and both T-shaped wall supports are located flat against the wall. Use 4 lag bolts and 4 washers to attach T-shaped wall supports. Locate at least one of the lag bolts from each support into a wood stud. If you do not have wood studs, use the appropriate type of wall anchor.
5. Tighten the hex nut on the T-shaped wall supports against the 84" pole.
6. Attach the springs and handles.



[Click here](#) for **Balanced Body Patent Data**.

[Clic aquí](#) para obtener datos de patentes de **Balanced Body**.

[Cliquez ici](#) pour consulter les données de brevet du corps équilibré.

[Fare clic qui](#) per i dati sui brevetti di **Balanced Body**.

[Klicken Sie hier](#) für **Balanced Body Patent Data**.

[Klicka här](#) för **Balanced Body Patent Data**.

[单击此处](#)以获取平衡车身专利数据。