

# Installing the Rolling Wheel Replacement Kit for Balanced Body® Studio Reformers

**NOTE:** Please read each step before starting. While it is possible to do this assembly with one person, it is highly recommended that two people perform this installation together.

## PARTS LIST

Please refer to Figure A for the parts and tools in this kit.

Diagram Number and Description	Qty	Part Number
1. Rolling Wheels	4	GEN9014
2. Carriage wheel bolts	4	GEN6379
3. Big washers	8	GEN9204
4. Nylock nuts	4	GEN9013
5. Small washers	4	GEN9492




Fig A

## TOOLS NEEDED

- » 1/2" wrench
- » Ratchet with a 1/2" socket

## INSTRUCTIONS

1. Remove the loops and the ropes from the carriage. Now flip the carriage over and place it with the upholstery side on the frame. See Figure B.




Fig B

2. Grab the hex nut with wrench and use a ratchet with a 1/2" socket to remove the wheel assembly. See Figure C.




Fig C

3. Discard all the old parts.
4. Figure D below shows the order in which the components go together.




Fig D

5. Securely tighten the wheel bolt with a ratchet while holding the nut with a wrench.
6. Repeat steps 2 through 5 to replace all the remaining wheels on the carriage. Check to make sure all the four wheels are spinning freely.
7. Clean all the wheels and the frame rail with a clean cloth to ensure a smooth ride.
8. Carefully lift the carriage and flip it back over and place it onto the frame rail. Roll it back and forth a few times to make sure that the ride is smooth and no contaminants were left on the wheels or rail.
9. Reinstall the ropes and the loops.
10. Attach at least one spring to a spring hook to keep the carriage home.

Questions? Contact Balanced Body Technical Support at 1-800-745-2837, +1-916-388-2838 or [info@pilates.com](mailto:info@pilates.com).