

How to Install the Contrology Reformer Non-Padded Footbar Cover

PARTS LIST

Description	Part Number	Qty
Contrology Non-Padded Footbar Cover	16155	1

1. Raise your footbar, to standard position, so the kickstand is supported in the clips down in the frame, if not already.
2. Clean the footbar. If using a mild detergent and water make sure to dry thoroughly before beginning.
3. Lower the cover onto the foam with the soft "Loop" side of the Velcro on the foot end of the reformer. The scratchy side of the Velcro will be on the carriage side of the reformer. Center it and pull it down over the legs, leaving it loose, Figure A.
4. Pull the cover around the vertical legs of the footbar and secure the Velcro to itself. This does not have to be perfect, this is to hold it in place when you work the top section.
5. Start connecting the Velcro to itself in the center on the top footbar section and work towards the ends. Be sure pull it tight and work out any wrinkles. If anything does not overlap or meet up, it is not pulled tight enough or aligned, pull apart and adjust as necessary.
6. After the horizontal (top) section is secure, detach one vertical leg Velcro. Rewrap it tightly and tuck the corner seam up and away from the carriage. See Figure B.
7. Go to the other vertical leg and pull the Velcro apart, re-adjust and pull this Velcro tight. Again tuck the corner seam up and away from the carriage.
8. Once finished the cover should look like Figure C (back view). Your footbar is ready to use.



Fig A



Fig B



Fig C